
08-0021

LIBERTA

Liberta E.P.E.



PACKAGE CONTENTS

- 1 x Tv Stand
- 1 x Pack of Accessories
- 1 x User Manual

PRODUCT CARE

- Please follow the instruction to assemble this item correctly.
- Don't make the screws be too loose or too tight.
- Please put the screws into the holes' position just as shown in the arrows of the image, and then clockwise rotate 90° or 180°.
- More product parts, it is recommended that two people install.
- The fittings pack contains small accessories that should be kept away from small children.

ΕΙΣΑΓΩΓΗ











Σας ευχαριστούμε που επιλέξατε το ντουλάπι τοίχου. Παρακαλούμε διαβάστε προσεκτικά αυτό το εγχειρίδιο χρήσης και κρατήστε το για μελλοντική αναφορά. Εάν χρειάζεστε βοήθεια, επικοινωνήστε μαζί μας μέσω email με τον αριθμό παραγγελίας σας και τα στοιχεία της.


ΠΕΡΙΕΧΟΜΕΝΑ ΣΥΣΚΕΥΑΣΙΑΣ


1 x Tv Stand
1 x Πακέτο Αξεσουάρ
1 x Εγχειρίδιο Χρήσης


ΦΡΟΝΤΙΔΑ ΠΡΟΪΟΝΤΟΣ

Παρακαλούμε ακολουθήστε τις οδηγίες για να συναρμολογήσετε αυτό το αντικείμενο σωστά.
Μην σφίγγετε τις βίδες υπερβολικά χαλαρά ή υπερβολικά σφιχτά.
Παρακαλούμε τοποθετήστε τις βίδες στις θέσεις των οπών, όπως φαίνεται στα βέλη της εικόνας, και στη συνέχεια περιστρέψτε δεξιόστροφα 90° ή 180°.
Για περισσότερα μέρη του προϊόντος, συνιστάται η εγκατάσταση από δύο άτομα.
Το πακέτο εξαρτημάτων περιέχει μικρά αξεσουάρ που πρέπει να φυλάσσονται μακριά από μικρά παιδιά.
Εγκαταστήστε το TV Stand σε συμπαγή τοίχο από τούβλο ή μπετόν.

A 6x35mm  x35	**B** 15x9.5mm  x35	**C** 6x30mm  x26	**D** 4x40mm  x12	**E** 3.5x12mm  x16
F  x8	**G** 3x14mm  x8	**H**  x6	**I**  x4	**J**  x2
K 4x12mm  x12	**CL**  x2	**CR**  x2	**DL**  x2	**DR**  x2



5
1
9
4
10
8
5
11
3
7
6
2
13
12


18
19
14
17
x2



15
16


1

Ax15	**Bx4**	**Cx4**




x2






2


Ex8	**CLx2**	**CRx2**








3

Ax10











4


Bx4	**Cx4**






5

Ax2	Bx2	Cx2




6

Cx4	Dx4




7

Bx3	Cx2




8




9

Bx3	Cx2



10

Hx6




Αφαιρέστε την προστατευτική μεμβράνη και κολλήστε τα προστατευτικά στο κάτω μέρος των ποδιών του ντουλαπιού



Peel off the film and stick it to the bottom of the cabinet feet.


11

Bx11	**Cx8**




12

Fx8	Gx8




13


Ix4



14


Jx2	**Kx12**






15

Dx8





x2





16

Ax8	Bx8










17

Ex8	**DLx2**	**DRx2**



18

