








Assembly Instructions/Οδηγίες Συναρμολόγησης






1
13
13
4
7
9
5
14
11
8
3
6
15
15
10
7
2
12

Hardware Fittings/Παρελκόμενα

				
Ax26pcs	Bx20pcs	Cx4pcs	Dx64pcs	Ex2pcs
				
Fx4pcs	Gx4pcs	Hx4pcs	Ix8pcs	Jx4pcs
				
Kx1pcs	Lx1pcs	Mx20pcs	Nx26pcs	


STEP 1/BHMA 1






	A1x6pcs
	A2x6pcs
	Bx4pcs


STEP 2/BHMA 2






	A1x6pcs
	A2x6pcs
	Bx4pcs


STEP 3/BHMA 3



	Kx1pcs
	Lx1pcs





STEP 4/BHMA 4





	Dx20pcs
	Gx4pcs


STEP 5/BHMA 5

















	A1x4pcs
	A2x4pcs
	Bx8pcs
	Cx4pcs


STEP 6/BHMA 6



	Hx4pcs


STEP 7/BHMA 7






	A1x10pcs
	A2x10pcs
	Bx4pcs


STEP 8/BHMA 8




	Dx20pcs
	Mx20pcs




STEP 9/BHMA 9



	Ix8pcs
	Jx4pcs




STEP 10/BHMA 10




	Dx4pcs
	Fx2pcs

STEP 11/BHMA 11




	Dx4pcs
	Fx2pcs

STEP 12/BHMA 12




In order to make the product more beautiful, please paste hardware N on the exposed holes

Για να κάνετε το προϊόν πιο όμορφο, παρακαλούμε επικολλήστε το μέρος N στις εκτεθειμένες οπές.



	Dx16pcs
	Nx26pcs

STEP 13/BHMA 13



Ex2pcs

STEP 14/BHMA 14

